

## When to use SACLOB



- The SACLOB should be used for indoor storage only.
- The space to be occupied should be free from sharp objects (small stones, metals, etc.) which may puncture or damage its bottom side.
- Rice seeds to be stored must be properly dried (MC of 12% or lower)
- Before using, check its sides to make sure it is free from punctures or holes.

### Using the SACLOB

The use of the SACLOB needs to be complemented with an oxygen meter so as to be able to monitor the oxygen content of the air inside. If there are no holes present, an oxygen level of 2 to 4% is usually attained within one week from the time the SACLOB is closed.

However, if there is no oxygen meter available, the filled SACLOB must be checked regularly for punctures or damages that may lose its hermetic condition.